MM-D330D

# DVD MICRO COMPONENT SYSTEM user manual

## Imagine the possibilities

Thank you for purchasing this Samsung product.

To receive more complete service,
please register your product at

www.samsung.com/register



## Safety Information

#### Safety Warnings

TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE THE COVER(OR BACK). NO USER-SERVICEABLE PARTS ARE INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol indicates "dangerous voltage" inside the product that presents a risk of electric shock or personal injury.

## CAUTION RISK OF ELECTRIC SHOCK DO NOT OPEN

**CAUTION**: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.



This symbol indicates important instructions accompanying the product.

#### WARNING

 To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

#### CAUTION

- Apparatus shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed on the apparatus.
- The Mains plug is used as a disconnect device and shall stay readily operable at any time.
- This apparatus shall always be connected to a AC outlet with a protective grounding connection.
- To disconnect the apparatus from the mains, the plug must be pulled out from the mains socket, therefore the mains plug shall be readily operable.

CLASS 1 LASER PRODUCT KLASSE 1 LASER PRODUKT LUOKAN 1 LASER LAITE KLASS 1 LASER APPARAT PRODUCTO LÁSER CLASE 1

#### CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

#### CAUTION

 INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

### Wiring the Main Power Supply Plug (UK Only)

#### IMPORTANT NOTICE

The main lead on this equipment is supplied with a moulded plug incorporating a fuse. The value of the fuse is indicated on the pin face of the plug and if it requires replacing, a fuse approved to BS1362 of the same rating must be used.

Never use the plug with the fuse cover removed. If the cover is detachable and a replacement is required, it must be of the same colour as the fuse fitted in the plug. Replacement covers are available from your dealer.

If the fitted plug is not suitable for the power points in your house or the cable is not long enough to reach a power point, you should obtain a suitable safety approved extension lead or consult your dealer for assistance.

However, if there is no alternative to cutting off the plug, remove the fuse and then safely dispose of the plug. Do not connect the plug to a main socket as there is a risk of shock hazard from the bared flexible cord.

Never attempt to insert bare wires directly into a main socket. A plug and fuse must be used at all times.

#### **IMPORTANT**

The wires in the main lead are coloured in accordance with the following code:- BLUE = NEUTRAL BROWN = LIVE

As these colours may not correspond to the coloured markings identifying the terminals in your plug, proceed as follows:-

The wire coloured BLUE must be connected to the terminal marked with the letter N or coloured BLUE or BLACK.

The wire coloured BROWN must be connected to the terminal marked with the letter L or coloured BROWN or RFD.

WARNING: DO NOT CONNECT EITHER WIRE TO THE EARTH TERMINAL WHICH IS MARKED WITH THE LETTER E OR BY THE EARTH SYMBOL \_\_\_\_\_\_\_, OR COLOURED GREEN OR GREEN AND YELLOW.

## Safety Information

#### Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause skipping.

Be especially careful not to scratch discs when handling them.

### Holding discs

- · Do not touch the playback side of the disc.
- · Hold the disc by the edges so that fingerprints will not get on the surface.
- · Do not stick paper or tape on the disc.

### Disc Storage

- · Do not keep in direct sunlight
- · Keep in a cool ventilated area
- · Keep in a clean Protection jacket. Store vertically.



### NOTE

- Do not allow the discs to become contaminated with dirt.
- Do not load cracked or scratched discs

### Handling and Storing Discs

If you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

. When cleaning, wipe gently from the inside to the outside of the disc



 Condensation may form if warm air comes into contact with cold parts inside the product. When condensation forms inside the product, it may not operate correctly. If this occurs, remove the disc and let the product stand for 1 or 2 hours with the power on.

#### License

- ABOUT DIVX VIDEO: DivX® is a digital video format created by DivX,Inc. This is an official DivX Certified device that plays DivX video, Visit www. divx.com for more information and software tools to convert your files. into DivX video. ABOUT DIVX VIDEO-ON-DEMAND: This DivX Certified® device must be registered in order to play DivX Video-on-Demand (VOD) content. To generate the registration code, locate the DivX VOD section in the device setup menu. Go to vod.divx.com with this code to complete the registration process and learn more about DivX VOD.
- "Pat. 7,295,673; 7,460,688; 7,519,274"



- DivX Certified® to play DivX ® video.
- · DivX ®, DivX Certified® and associated logos are trademarks of DivX,Inc.and are used under license.

#### Copyright

© 2011 Samsung Electronics Co., Ltd. All rights reserved.

#### **Copy Protection**

- Many DVD discs are encoded with copy protection. Because of this. you should only connect your product directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.
- This product incorporates copyright protection technology that is protected by U.S. patents and other intellectual property rights. Use of this copyright protection technology must be authorized by Macrovision, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision. Reverse engineering or disassembly is prohibited.

#### Accessories

Check for the supplied accessories below.



## Contents

#### SAFETY INFORMATION

- 2 Safety Warnings3 Accessories 3 Cautions on Handling and Storing Discs
- 3 License3 Copyright
- 3 Copy Protection

### **GETTING STARTED**

- 5 Precautions
- 5 Icons that will be used in manual
- 6 Disc Types and Characteristics9 Description
- Front Panel 9
- 9 Top Panel
- Top Fanc. Rear Panel 10
- 11 Remote control

### CONNECTIONS

- Connecting the Speakers
   Connecting the Video Out to your TV
   Connecting External Components
   Connecting the TM Antenna
   Connecting Headphones

### **SETUP**

- 16 Before Starting (Initial Setting)
- 16 Setting the Setup menu
- 17 Display
- 17 TV Aspect
- 17 Audio
- 17 DRC (Dynamic Range Compression) AUDIO-SYNC
- 17
- 18 System
- 18 Initial Setting
- 18 DivX(R) Registration
- 18 Language
- 18 Security
- 18 Parental Rating
- 18 Change Password
- 18 Support
- Product Information

#### **BASIC FUNCTIONS**



- 19 Audio CD(CD-DA)/MP3/WMA Playback
- 20 JPEG File Playback
- 20 Using the Playback Function
- 25 Sound Mode
- 26 Mute Function
- 26 Display Function
- 27 Listening to Radio27 About RDS Broadcasting(optional)
- 29 Setting the Clock
- 29 Timer Function
- 30 Sleep Timer Function

## ADVANCED FUNCTIONS

- **USB Function**
- Recording Function 31

## OTHER INFORMATION

- Troubleshooting 33
- 34 Language code list
- 35 Specifications

## Gettina Starte

- . Ensure that the AC power supply in your house complies with the identification sticker located on the back of your product.
- Install your product horizontally, on a suitable base (furniture), with enough space around it for ventilation (7.5~10cm).
- . Do not place the product on amplifiers or other equipment which may become hot. Make sure the ventilation slots are not
- · Do not stack anything on top of the product.
- . Before moving the product, ensure the Disc Insert Hole is
- . In order to disconnect the product completely from the power supply, remove the AC plug from the wall outlet, especially when left unused for a long period of time.
- . During thunderstorms, disconnect the AC plug from the wall outlet. Voltage peaks due to lightning could damage
- · Do not expose the product to direct sunlight or other heat sources. This could lead to overheating and malfunction of the product.
- · Protect the product from moisture, and excess heat or equipment creating strong magnetic or electric fields (i.e. speakers.).
- . Disconnect the power cable from the AC supply if the product malfunctions. Your product is not intended for industrial use.
- Use of this product is for personal use only.
- · Condensation may occur if your product or disc has been stored in cold temperatures. If transporting the product during the winter, wait approximately 2 hours until the product has reached room temperature before using.
- · The batteries used with this product contain chemicals that are harmful to the environment. Do not dispose of batteries in the general household trash.

#### Icons that will be used in manual

Make sure to check the following terms before reading the user manual.

_		
Icon	Term	Definition
DVD	DVD	This involves a function available with DVD-Video or DVD±R/±RW discs that have been recorded and finalised in Video Mode.
(S)	CD	This involves a function available with a data CD (CD-DA, CD-R/-RW).
NP3	MP3	This involves a function available with CD-R/-RW discs.
JPEG	JPEG	This involves a function available with CD-R/-RW discs.
<b>( ( ( ( ( ( ( ( ( (</b>	DivX	This involves a function available with MPEG4 discs. (DVD±R/±RW, CD-R/-RW)
!	CAUTION	This involves a case where a function does not operate or settings may be canceled.
<b>\(\rightarrow\)</b>	NOTE	This involves tips or instructions on the page that help each function operate.

- · Figures and illustrations in this User Manual are provided for reference only and may differ from actual product appearance.
- · An administration fee may be charged if either
  - a. an engineer is called out at your request and there is no defect in the product (i.e. where you have failed to read this user manual)
  - b. you bring the unit to a repair centre and there is no defect in the product
  - (i.e. where you have failed to read this user manual).
- The amount of such administration charge will be advised to you before any work or home visit is carried out.

## Getting Started

#### **Disc Types and Characteristics**

### **Region Code**

The product and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.

Disc Type	Region Code	Area
		The U.S., U.S. territories and Canada
	2	Europe, Japan, the Middle East, Egypt, South Africa, Greenland
	(3)	Taiwan, Korea, the Philippines, Indonesia, Hong Kong
DVD-VIDEO		Mexico, South America, Central America, Australia, New Zealand, Pacific Islands, Caribbean
		Russia, Eastern Europe, India, most of Africa, North Korea, Mongolia
	6	China

### Disc types that can be played

Disc Types & Mark (Logo)	Recorded Signals	Disc Size	Max. Playing Time
	VIDEO	12 cm	Approx. 240 min. (single-sided)
DVD			Approx. 480 min. (double-sided)
DVD-VIDEO		8 cm	Approx. 80 min. (single-sided)
			Approx. 160 min. (double-sided)
		12 cm	74 min.
AUDIO-CD	AUDIO	8 cm	20 min.
DIVX	AUDI0	12 cm	_
DivX	+ VIDEO	8 cm	_

### Do not use the following types of disc!

- . LD, CD-G, CD-I, CD-ROM, DVD-ROM and DVD-RAM discs cannot be played on this product. If such discs are played, a <WRONG DISC FORMAT> message appears on the TV screen.
- · DVD discs purchased abroad may not play on this product.

If such discs are played, a <Wrong Region. Please check Disc.> message appears on the TV screen.

### Disc Types And Disc Format

This product does not support Secure (DRM) Media files.

#### **CD-R Discs**

- . Some CD-R discs may not be playable depending on the disc recording device (CD-Recorder or PC) and the condition of the disc.
- Use a 650MB/74 minute CD-R disc. Do not use CD-R discs over 700MB/80 minutes as they may not be played back.
- · Some CD-RW (Rewritable) media, may not be playable.
- . Only CD-Rs that are properly "closed" can be fully played. If the session is closed but the disc is left open, you may not be able to fully play the disc.

#### CD-R MP3 Discs

- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- MP3 file names should contain no blank spaces or special characters (, / = +).
- Use discs recorded with a compression/ decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank seament.
- . If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.
- A maximum of 999 tracks can be played per CD.
- · A maximum of 300 folders can be played per CD.

#### **CD-R JPEG Discs**

- · Only files with the "jpg" extensions can be played.
- If the disc is not closed, it will take longer to start playing and not all of the recorded files may be played.
- Only CD-R discs with JPEG files in ISO 9660 or Joliet format can be played.
- · JPEG file names should be 8 characters or less in length and contain no blank spaces or special characters (, / = +).
- · Only a consecutively written multisession disc can be played. If there is a blank segment in the multisession disc, the disc can be played only up to the blank segment.
- A maximum of 999 images can be stored on a folder.
- · When playing a Kodak/Fuji Picture CD, only the JPEG files in the picture folder can be played.
- Picture discs other than Kodak/Fuii Picture CDs may take longer to start playing or may not play at all.

#### DVD±R/±RW, CD-R/RW Discs

 Software updates for incompatible formats are not supported.

(Example: QPEL, GMC, resolution higher than 800 x 600 pixels, etc.)

 If a DVD-R/-RW disc has not been recorded. properly in DVD Video format, it will not be playable.

#### DivX (Digital internet video express)

DivX is a video file format developed by Microsoft and is based on MPEG4 compression technology to provide audio and video data over the Internet in real-time.

MPEG4 is used for video encoding and MP3 for audio encoding so that the users can watch a movie at near DVD-quality video and audio.

#### Supported Formats (DivX)

This product only supports the following media formats. If both video and audio formats are not supported, the user may experience problems such as broken images or no sound.

#### Supported Video Formats

Format	Supported Versions
AVI	DivX3.11~DivX5.1, XviD
WMV	V1/V2/V3/V7

#### Supported Audio Formats

Format	Bit Rate	Sampling Frequency
MP3	80~320kbps	44.1khz
WMA	56~128kbps	44.1KIIZ
AC3	128~384kbps	44.1/48khz

- · Aspect Ratio: Although the default DivX resolution is 640x480 pixels, this product supports up to 720x480 pixels. TV screen resolutions higher than 800 will not be supported.
- · When you play a disc whose sampling frequency is higher than 48khz or 320kbps, you may experience shaking on the screen during playback.
- · Sections with a high frame rate might not be played while playing a DivX file.
- · Since this product only provides encoding formats authorized by DivX Networks, Inc., a DivX file created by the user might not play.

## Getting Started

### **USB Host Specification**

#### **USB Host Specification**

- Supports USB 1.1 or USB 2.0 compliant devices.
- Supports devices connected using the USB A type cable.
- Supports UMS (USB Mass Storage Device) V1.0 compliant devices.
- Supports the device of which the connected drive is formatted in the FAT (FAT, FAT16, FAT32) file system.

#### Non-compliance

- Does not support a device that requires installing a separate driver on the PC (Windows).
- Does not support connection to a USB hub.
- A USB device that is connected using the USB extension cable may not be recognized.
- A USB device requiring a separate power source needs to be connected to the product with the separate power connection.

#### Operational Limitations

- If the connected device has multiple drives (or partitions) installed, only one drive (or partition) can be connected.
- A device supporting USB 1.1 alone may cause a difference in the picture quality, depending on the device.

## USB Devices that can be used with the product


- USB Storage Device, MP3 Player, Digital Camera
- Removable HDD
  - Removable HDDs equipped with less than 160 Gbytes are supported. Removable HDDs equipped with 160Gbytes or more may not be recognized, depending on the device.
  - If the connected device does not work due to insufficient power supply, you can use a separate power cable to supply power so that it can work properly. The connector of the USB cable may differ, depending on the manufacturer of the USB device.
- USB card Reader: One slot USB card reader and Multi slot USB card reader.
  - The USB card reader may not be supported, depending on the manufacturer.

- If you install multiple memory devices into a multi card reader, you may experience problems.

#### Supported file Formats


Format	Still Picture	Music		Movie	
File name	JPG	MP3	WMA	WMV	DivX
File extension	JPG .JPEG	.MP3	.WMA	.WMV	.AVI
Bit rate	-	80~320 kbps	56~128 kbps	4Mbps	4Mbps
Version	-	-	V8	V1,V2, V3,V7	DivX3.11~ DivX5.1, XviD
Pixel	640x480	-	-	72	0x480
Sampling Frequency	-	44.1kHz	44.1kHz	44.1KH	lz~ 48KHz

- CBI (Control/Bulk/Interrupt) is not supported.
- Digital Cameras that use PTP protocol or require additional program installation when connected to a PC are not supported.
- Some MP3 players, when connected to this product, may not operate depending on the sector size of their file system.
- The USB host function is not supported if a product that transfers media files by its manufacturer specific program is connected.
- Does not operate with Janus enabled MTP (Media Transfer Protocol) devices.
- The USB host function of this product does not support all USB devices.



- WINDOW DISPLAY 1.
- COMPACT DISC COMPARTMENT 2.
- 3. USB JACK
- AUX IN JACK 4.
- 5. PHONES JACK
- 6. **VOLUME CONTROL BUTTON**


### Top Panel



- 1. POWER BUTTON
- 2. USE REC BUTTON
- 3. FUNCTION BUTTON
- 4. SKIP/SEARCH FUNCTION BUTTON
- 5. TUNING MODE OR STOP BUTTON
- 6. PLAY/PAUSE BUTTON
- 7. SKIP/SEARCH FUNCTION BUTTON
- 8. OPEN/CLOSE BUTTON

## Getting Started

#### Rear Panel



1	2.0 CHANNEL SPEAKER OUTPUT CONNECTORS Connect the front speakers.	
2	ONLY FOR SERVICE	This jack is just for testing, please don't use it.
3	FM ANTENNA JACK	Connect the FM antenna.
4	VIDEO OUT JACK	Connect your TV's Video Input jack (VIDEO IN) to the VIDEO OUT jack.
5	COMPONENT VIDEO OUTPUT JACKS	Connect a TV with Component video inputs to these jacks.


#### Where to Install Your Micro-Compact System

To take full advantage of your new Micro-compact system, follow these installation instructions before connecting the unit.

- Install the system on a flat, stable surface.
- Never place this unit on carpeting.
- Never place this unit in an outdoor area.
- Maintain an open space of approximately 6 inches (15 cm) on the sides and rear of the system, for ventilation purposes.
- Make sure that you have enough room to open the compact disc compartment easily.
- Place the Speakers at a reasonable distance on either side of the system to ensure good stereo sound.
- Direct the Speakers towards the listening area.
- For optimum performance, make sure that both speakers are placed at an equal distance above the floor.

#### Remote control

### Tour of the Remote Control




- \* This product does not support the DISC SKIP/SYNC function with marked [\*].
- \* This product may not have the RDS function depending on your region.


### Installing batteries in the Remote Control

### NOTE

- Place batteries in the remote control so they match the polarity: (+) to (+) and (-) to (-).
- Always replace both batteries at the same time.
- Do not expose the batteries to heat or a flame.
- The remote control can be used up to approximately 23 feet (7 meters) in a straight line.



Before moving or installing the product, be sure to turn off the power and disconnect the power cord.



#### Position of the product

Place it on a stand or cabinet shelf, or under the TV stand.

#### Selecting the Listening Position

The listening position should be located about 2.5 to 3 times the distance of the TV's screen size away from the TV. Example: For 32" TV's 6.56 ~ 7.87 feet (2~2.4 m) For 55" TV's 11.5 ~ 13.1 feet (3.5~4 m)

### 

Place these speakers in front of your listening position, facing inwards (about 45°) toward you. Place the speakers so that their tweeters will be at the same height as your ear.

### ! CAUTION


- Do not let children play with or near the speakers. They could get hurt if the speaker falls.
- When connecting the speaker wires to the speakers, make sure that the polarity (+/-) is correct.

### **™** NOTE

If you place a speaker near your TV set, screen color may be distorted because of the magnetic field generated by the speaker. If this occurs, place the speaker away from your TV set.

### Connecting the Video Out to your TV

Choose one method for connecting to a TV.




### METHOD 1: Component Video(BETTER QUALITY)

If your television is equipped with Component Video inputs, connect a Component video cable (not supplied) from the COMPONENT OUT (Pr, Pb and Y) Jacks on the back of the product to the Component Video Input Jacks on your TV.

### METHOD 2: Composite Video(GOOD QUALITY)

Connect the supplied Video cable from the VIDEO OUT jack on the back of the product to the VIDEO IN jack on your TV.

### **Connecting External Components**




### Connecting an External Analog Component

Analog signal components such as a VCR.

- 1. Connect AUX IN (Audio) on the player to the Audio Out of the external analog component.
- 2. Press the F ( button to select AUX input. You can select AUX by pressing the FUNCTION button on the remote control.

### Connecting the FM Antenna




- 1. Connect the FM antenna supplied to the FM Antenna jack.
- 2. Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.



This product does not receive AM broadcasts.

### **Connecting Headphones**

You can connect a set of headphones to your micro component system so that you can listen to music or radio programmers without disturbing other people in the room. The headphones must have a 3.5ø jack or an appropriate adapter.



- 1. Connect the headphones to the PHONES jack on the front panel.
  - . The loudspeakers are no longer used to output the sound.



Prolonged use of headphones at a high volume may damage your hearing.

#### Before Starting (Initial Setting)

1. Press the POWER button when it is plugged in TV for the first time. Initial Setting screen will be displayed.




- 2. Press the ▲ ▼ buttons to select the desired language, then press the ENTER button.
- Press the ▲ ▼ buttons to select desired TV Aspect, then press the ENTER button.



- If you move to the previous screen, press and hold Red(A) button.
- Once you select a menu language, you can change it by pressing the STOP ( ) button on the top panel for more than 5 seconds with no disc.
- When the Initial Setting screen does not appear, refer to Initial Setting. (see page 18)

#### Setting the Setup menu

The access step may differ depending on the selected menu. The GUI (Graphical User Interface) in this manual may differ, depending on the firmware version.



- 0 MENU BUTTON: Display the home menu.
- **RETURN** BUTTON: Return to the previous 0 setup menu.

#### **ENTER / DIRECTION BUTTON**

- Move the cursor and select an item. 0 Select the currently selected item. Confirm the setting.
- 4 EXIT BUTTON: Exit the setup menu.



1. Press the POWER button in NO DISC mode. or

During playback, press STOP button twice.

- 2. Press the ◀▶ buttons to select Settings, then press the ENTER button.
- 3. Press the ▲▼ buttons to select desired menu, then press the ENTER button.
- 4. Press the ▲▼ buttons to select desired sub-menu, then press the ENTER button.
- Press the ▲▼ buttons to select desired item, then press the ENTER button.
- 6. Press the EXIT button to exit the setup menu.

#### **Display**

You can configure various display optionals such as the TV Aspect.

### TV Aspect

Depending on the type of television you have, you may want to adjust the screen setting.



#### 4:3 Pan-Scan



Select when you want to see the 16:9 video supplied by the DVD without the black bars on top and bottom, even though you have a TV with a 4:3 ratio screen(extreme left and right portion of the movie picture will be cut off).

#### · 4:3 Letter Box



Select when you want to see the total 16:9 ratio screen DVD supplies, even though you have a TV with a 4:3 ratio screen. Black bars will appear at the top and bottom of the screen.

#### 16:9 Wide



You can view the full 16:9 picture on vour widescreen TV.

### **◎** NOTE

- If a DVD is in the 4:3 ratio, you cannot view it in the wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.
- Depending on the type(NTSC or PAL) of main unit you have, the TV display picture may be different.

#### Audio

### DRC (Dynamic Range Compression)


This feature balances the range between the loudest and quietest sounds. You can use this function to enjoy Dolby Digital sound when watching movies at low volume at night.



You can select either Full, 6/8, 4/8, 2/8, Off.

#### AUDIO-SYNC

Video and audio sync may not match with digital TV. If this occurs, adjust the audio delay time to match the video



· You can set the audio delay time between 0 mSec and 300 mSec. Set it to the optimal status.

#### System

### Initial Setting

By using the Initial Setting, you can set language and TV aspect setting.

### DivX(R) Registration

View DivX(R) VOD Registration Code to purchase and play DivX(R) VOD content.

#### Language

You can select the language you prefer for on-screen menu, disc menu, etc.



OSD Language	Select the language for the on- screen displays.
Disc Menu	Select the language for the disc menu displays.
Audio	Select the language for disc audio.
Subtitle	Select the language for disc subtitles.

- \* To select another language, select OTHERS of Disc Menu, Audio and Subtitle, and enter the language code of your country (see page 34).
- You cannot select OTHERS in the OSD Language menu



 The selected language will only appear if it is supported on the disc.

#### Security

The Parental Lock function works in conjunction with DVDs that have been assigned a rating which helps you control the types of DVDs that your family watches. There are up to 8 rating levels on a disc.

### Parental Rating

Select the rating level you want to set.

A larger number indicates that the program is intended for adult use only. For example, if you select up to Level 6. discs that contain Level 7. 8 will not play.

Enter the password and then press the ENTER button.

- The password is set to "0000" by default.
- Once the setup is complete, you will be taken to the previous screen.

### Change Password

Select Change and enter the 4-digit password to set the parental lock using the number buttons on the remote control



### If you forgot your password

In "NO DISC" mode, press and hold the STOP

(■) button on the top panel for 5 seconds or more. All settings will revert to the factory settings.

#### Support

#### Product Information

Provide contact information for assistance with your product.

## **Basic Functions**

#### Disc Playback

- Press the OPEN/CLOSE button.
- 2. Place a disc gently into the disc Compartment with the disc's label facing up.
- 3. Press the OPEN/CLOSE button to close the disc Compartment.

### **<sup>®</sup>** NOTE

- Resume function: When you stop disc play, the product remembers where you stopped, so when you press PLAY button again, it will pick up where you left off. (This function works only with DVDs.) Press the STOP button twice during playback to disable the Resume function.
- If no buttons are pressed on the product or remote control for more than 3 minutes when the product is in Pause mode, it will be changed to Resume stop mode. and after another 5 minutes in Resume stop mode, it will be changed to screen saver mode.
- The initial screen may appear different, depending on the content of the disc.
- Pirated discs will not run in this product because it violates the CSS (Content Scrambling System: a copy protection system) recommendations.
- DTS Audio is not supported.
- Will appear when an invalid button is pressed.

### TV Screen Saver/Power Saving Function

- If the product is left in the stop mode more than 5 minutes without any user interface, a screen saver will appear on your TV.
- . If the product is left in the screen saver mode for more than 20 minutes, the power will automatically turn off.

#### Audio CD(CD-DA)/MP3/WMA Playback







- 1. Insert an Audio CD(CD-DA) or an MP3 Disc into the disc Compartment.
  - . For an Audio CD, the first track will be played automatically.
    - Press the I buttons to move to the previous/next track.
  - For the MP3/WMA disc, press the ▲▼◀▶ buttons to select Music, then press the ENTER button.
    - Press the ▲▼◀▶ buttons to select a desired file and press the ENTER button.
  - Press the ◆ buttons to move to the previous/next pages.
- Press the STOP (■) button to stop playback.

#### **◎** NOTE

- Some MP3/WMA-CDs may not play, depending on the recording mode.
- Table of contents of a MP3-CD varies depending on the MP3/WMA track format recorded on the disc.
- WMA-DRM files cannot be played.

## Basic Functions

### JPEG File Playback

Images captured with a digital camera or camcorder, or JPEG files on a PC can be stored on a CD and then played back with this product.

- 1. Insert a JPEG disc on the disc Compartment.
- Press the ◀.▶ buttons to select the Photos. and then press the ENTER button.
- 3. Press the ▲▼ buttons to select the folder you want to play, and then press the ENTER button.
- Press the ▲ ▼ buttons to select the photo you want to play, and then press the ENTER button.
  - . The selected file will play and slide show will
  - To stop slide show, press the PAUSE (II) button.
  - You can view the previous/next file by pressing the ◀,▶ buttons during the slideshow mode.



#### **Rotate Function**



Press the GREEN(B) or YELLOW(C) button during the PAUSE mode.

- GREEN(B) Button: Rotate 90° Counterclock wise.
- YELLOW(C) Button: Rotate 90° Clockwise.



The maximum resolutions supported by this product are 5120 x 3480 (or 19.0 MPixel) for standard JPEG files and 2048 x 1536 (or 3.0 MPixel) for progressive image files.

### **Using the Playback Function**

#### Forward/Reverse Search










Press the ◀▶ buttons for Search Function.





No sound is played in search mode.

### Skipping Scenes/Songs









Press the I buttons.

- Each time the button is pressed during playback. the previous or next chapter, track or directory (file) will be played.
- · You cannot skip chapters consecutively.

### Slow Motion Play



Press the PAUSE (II) button and then ▶ button for Slow Motion play.







- No sound is heard during slow playback.
- Reverse slow playback does not work.

### Step Motion Play





Press the PAUSE button repeatedly.

 The picture moves forward one frame each time the button is pressed during playback.



No sound is heard during step motion playback.



### 5 Minute Skip function



During playback, press the ◀,▶ button.

- · Playback skips 5 minutes forward whenever you press the button.
- Playback skips 5 minutes backward whenever you press the ◀ button.



You can operate this function only on the DivX.

### Using the Disc Menu



You can view the menus for the audio language, subtitle language, profile, etc.

- 1. During playback, press and hold the DISC MENU button on the remote control.
- Press the ▲▼◀► buttons to make the desired selection, then press the ENTER button.



 Depending on the disc, menu setup items may vary and this menu may not be available.



### Using the Title Menu



For DVDs containing multiple titles, you can view the title of each movie.

- 1. During playback, press and hold the TITLE MENU button on the remote control.
- 2. Press the ▲▼◀► buttons to make the desired selection, then press the ENTER button.



 Depending on the disc, menu setup items may vary and this menu may not be available.



## Basic Functions

### Repeat Playback









#### DVD/DivX Repeat

You can repeat the title, chapter or the section(A-B Repeat) of the DVD/DivX.



- 1. During the DVD/DivX playback, press and hold the REPEAT button on the remote control.
- 2. Press the ▲▼ buttons to select a desired repeat mode, then press the ENTER button.
- 3. Press the ▲ ▼ buttons to select Off to return to normal play, then press the ENTER button.





$$Off \rightarrow Title \rightarrow Folder \rightarrow All$$

### CD/MP3 Repeat

1. During the CD/ MP3 playback, press and hold the REPEAT button repeatedly to select the repeat mode you want.



(Normal → Repeat Track → Repeat All → Random → Repeat Section A-B)



(Normal → Repeat Track→ Repeat DIR → Repeat All→ Random)

### A-B Repeat Playback





You can repeatedly play back a designated section of a DVD or CD.

- 1. During the DVD disc or CD playback, press and hold the **REPEAT** button on the remote control.
- 2. For DVD, press the ▲▼ buttons to select A-. For CD press and hold the REPEAT button repeatedly until (AB) appears on the TV.
- 3. Press the ENTER button at the point where you want repeat play to start (A).
- 4. Press the ENTER button at the point where you want repeat play to stop (B).
- 5. To return to normal playback, For DVD, press and hold the REPEAT button to select to REPEAT OFF. For CD, press and hold the REPEAT button to select to 

  ...

### **™** NOTE

The A-B Repeat function does not operate with DivX, MP3 or JPEG discs.



### **Displaying Disc Information**









- 1. During the playback, press the TOOLS button on the remote control.
- Press the ▲▼ buttons to select the desired.
- 3. Press the ◀▶ buttons to make the desired setup change and then press the ENTER button.
  - You may use the number buttons of the remote control to control some item.
- 4. To make Disc information disappear, press the TOOLS button again.

### **™** NOTE

- If you are playing contents from the tools menu, some functions may not be enabled depending on the disc.
- Some tools menu may differ depending on discs and files.

#### TOOLS menu

■ Title( ): To access the desired title

- when there is more than one in the disc. For example, if there is more than one movie on a DVD, each movie will be identified as a Title.
- Chapter( ♣): Most DVD discs are recorded in chapters so that you can quickly find a specific chapter.
- Playing time( ): Allows playback of the film from a desired time. You must enter the starting time as a reference. The time search function does not operate on some discs.
- Audio( ): Refers to the film's soundtrack language. A DVD Disc can contain up to 8 audio languages.
- Subtitle( ): Refers to the subtitle languages available in the disc. You will be able to choose the subtitle languages or, if you prefer, turn them off from the screen. A DVD Disc can contain up to 32 subtitle languages.
- Angle( ≥ ): When a DVD contains multiple angles of a particular scene, you can use the Angle function.

### Selecting the Audio Language





- 1. Press the TOOLS button.
- Press the ▲▼ buttons to select AUDIO ( ) display.
- Press the ◀▶ buttons to select the desired audio language.
  - Depending on the number of languages on a DVD disc, a different audio language is selected each time the button is pressed.



## **Basic Functions**

### Selecting the Subtitle Language





### **Angle Function**



- 2. Press the ▲▼ buttons to select SUBTITLE ( ......) display.
- 3. Press the ◀▶ buttons to select the desired subtitle language.
  - · Depending on the number of languages on a DVD disc, a different subtitle language is selected each time the button is pressed.





- Depending on the disc, the Subtitle and Audio Language functions may not be available.
- On the DivX fi le format, the subtitle languages may be represented by only numbers.

### Caption Function

- · You must have some experience with video extraction and editing in order to use this feature properly.
- . To use the caption function, save the caption file (\*.smi) in the same file name as that of the DivX media file (\*.avi) within the same folder. Example. Root Samsung 007CD1.avi Samsung\_007CD1.smi
- Up to 60 alphanumeric characters or 30 East Asian characters (2 byte characters such as Korean and Chinese) for the file name.
- . The subtitle of DivX files are \*.smi, \*.sub, \*.srt over 148 kbyte is not supported.



This function allows you to view the same scene in different anales.

- 1. Press the TOOLS button
- 2. Press the ▲▼ buttons to select ANGLE ( 😂 )
- 3. Press the ◀▶ buttons to select the desired anale.



The Angle function works only with discs on which multiple angles have been recorded.

**24** English

#### **Sound Mode**

#### EQ

Your micro-compact system is equipped with a preset equalizer that allows you to choose the most appropriate balance between treble and bass frequencies, according to the type of music you are listening to.

Press the EQ button until the required optional is selected.

Select	To obtain a
OFF	Normal balance (linear)
RANCHA	Banlace suitable for Rancha Music.
SAMBA	Banlace suitable for Samba Music.
CUMBIA	Banlace suitable for Cumbia Music.
HABANA	Banlace suitable for Habana Music.
BOOM BA	Banlace suitable for Boom Ba Music.
REGGAE	Balance suitable for Reggae Music.
PARTY	Balance suitable for Party Music.
POP	Balance suitable for Pop Music.
	Balance suitable for HipHop Music.
ROCK	Balance suitable for Rock Music.
JAZZ	Balance suitable for Jazz Music.
CLASS	Balance suitable for Class Music.
FLAT	
STA+EQ	Banlace suitable for Stadium Music.
DYN+S	Banlace suitable for Dynamic spot Music.
VIR+S	
U1 B 0	Banlace suitable for User 1 mode Music
	Banlace suitable for User 2 mode Music

Set the BASS (left numeric), MIDDLE (middle numeric), TREBLE (right numeric) level.

> Press the ENTER button when you select the U1 B 0 / U2 B 0 /U3 B 0.

Result: The BASS level(left numeric) flash.

Press the TUNING o or w button to select from -06 to 06.

Press the ENTER button.

Result: The MIDDLE level(middle numeric) flash.

Press the TUNING o or w button to select from

Press the ENTER button.

Result: The TREBLE level(right numeric) flash. Press the TUNING ^ or > button to select from

-06 to 06.

Press the ENTER button.

Result: setting is completed.



### NOTE

- When CD Recording, the EQ function can't work and the EQ automatically covery to "OFF" mode.
- This function is not available during playback of an DVD disc.
- If no buttons is pressed within 8 seconds, the setting will automatically be cancelled. and the anterior setting will be saved.

#### P BASS

Your micro-compact system has a bass amplification function called Power Bass. This function makes the sound more powerful and real.

1. Press and hold the SOUND button on the remote control

Result: "P BASS" is displayed.

2. To cancel this function, press this button again, "P OFF" is displayed for a few seconds.



### NOTE

 When CD Recording, the Power Bass function can't work and the Power Bass automatically covery to "OFF" mode.

## Basic Functions

### **Mute Function**

This is useful when answering a doorbell or telephone call.

#### 1. Press MUTE button:

- ' MUTE' appears in the display.
- To switch the sound back on, press the MUTE button again or the VOL-, + button.



### **Display Function**

You can view all functions available on the display, adjust the brightness of the display.

- 1. Each time you press and hold the DISPLAY button on the remote control, the display mode will change as follows:
  - The Demo function

All functions available on the system appear on the front panel display.

#### The Dimmer function

The Dimmer function is selected and the display darkens.

Display ON

The Display turns on.

Clock ON

The Clock you set is displayed.



#### Listening to Radio

#### Using buttons on the Remote Control

- 1. Press the FUNCTION button to select FM.
- 2. Tune in to the desired station.
  - Automatic Tuning 1: Press the STOP button to select PRE 01 and then press TUNING (^
     buttons to select the preset station.

  - Manual Tuning: Press the STOP button to select MANUAL and then briefly press the TUNING (^ ~) button to increase or decrease the frequency incrementally.

### Using buttons on the product

- 1. Press the F( ) button to select FM.
- 2. Select a broadcast station.
  - Automatic Tuning 1 : Press the STOP (■)
    button to select PRESET and then press the
    I◄
     I◄
  - Automatic Tuning 2: Press the STOP (■) button to select MANUAL and then press and hold the I◄ ► buttons to automatically search the band.
  - Manual Tuning: Press the STOP (■) button to select MANUAL and then press the I◄
     buttons to tune in to a lower or higher frequency.

### Setting Mono/Stereo

Press the MO/ST button.

- Each time the button is pressed, the sound switches between STEREO and MONO.
- In a poor reception area, select MONO for a clear, interference-free broadcast.




This applies only when listening to an FM station

### Presetting Stations

Example: Presetting FM 89.10 in the memory

- 1. Press the FUNCTION button to select FM.
- 2. Press the STOP (■) button on the top panel to select <MANUAL> mode.
- 3. Press the TUNING (△✓) button to select <89.10>.
- 4. Press the **FNTFR** button
  - Number flashes on the display.
- Press the I → buttons on the top panel to select preset number.
  - · You can select between 1 and 15 presets.
- 6. Press the ENTER button again.
  - Press the ENTER button before number disappears from the display.
  - Number disappears from the display and the station is stored in memory.
- 7. To preset another station, repeat steps 2 to 6.
  - To tune in to a preset station, press the TUNING (~~) buttons on the remote control to select a channel.



## About RDS broadcasting(optional)

## Using the RDS (Radio Data System) to receive FM stations

RDS allows FM stations to send an additional signal along with their regular program signals. For example, the stations send their station names, as well as information about what type of program they broadcast, such as sports or music, etc.

When tuned to an FM station which provides the RDS service, the RDS indicator lights up on the display.

#### Description on RDS function

- PTY (Program Type): Displays the type of programme currently being broadcast.
- PS NAME (Program Service Name): Indicates the name of broadcasting station and is composed of 8 characters.
- RT (Radio Text): Decodes the text broadcast by a station (if any) and is composed of maximum 64 characters.

English 27

## Rasic Functions

- . CT (Clock Time): Decodes the real time clock from the FM frequency. Some stations may not transmit PTY, RT or CT information therefore this may not be displayed in all cases.
- . TA (Traffic Announcement): When this symbol flashes it shows that the traffic announcement is in progress.

#### NOTE

 RDS may not operate correctly if the station tuned is not transmitting RDS signal properly or if the signal strength is weak.

### To show the RDS signals

You can see the RDS signals the station sends on the display.

Press the RDS DISPLAY button while listening to an FM station

 Each time you press the button, the display change to show you the following information: PS NAME → RT→ CT → Frequency

PS (Program Service)	While searching, <ps> appears and then the station names will be displayed. <no ps=""> appears if no signal is sent.</no></ps>
RT(RadioText)	While searching, <pre><pre><pre>RT&gt; appears and<pre>then text messages the station sendswill be displayed. </pre><pre><pre><pre><pre><pre></pre></pre><pre><pre><pre></pre><pre><pre><pre><pre><pre><pre><pre>&lt;</pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre></pre>
	Decodes the real time clock from the FM frequency.
CT (Clock Time)	Some stations may not transmit PTY, RT or CT information therefore this may not be displayed in all cases.
Frequency	Station frequency (non-RDS service)

### About characters shown in the display

When the display shows PS,or RT signals,the following characters are used.

- . The display window cannot differentiate upper case and lower case letters and always uses upper case letters.
- · The display window cannot show accented letters, <A.> for instance, may stands for accented <A's> like <À, Â, Ä, Á, Å and Ã.>

#### PTY (Program Type) indication and

#### PTY-SEARCH function

One of the advantages of the RDS service is that you can locate a particular kind of program from the preset channels by specifying the PTY codes.

### To search for a program using the PTY codes

#### Before you start!

- The PTY Search is only applicable to preset stations.
- · To stop searching any time during the process, press the STOP button while searching.
- There is a time limit in doing the following steps. If the setting is cancelled before you finish, start from step 1 again.
- When pressing the buttons on the primary remote control, make sure that you have selected the FM station using the primary remote control.



- 1. Press the RDS PTY button while listening to an FM station.
- 2. Press the TUNING ( >>> ) button until the PTY code you want appears on the display.
  - . The display gives you the PTY codes described to the right.
- 3. Press the RDS PTY button again, while the PTY code selected in the previous step is still on the display.
  - The centre unit searches 30 preset FM stations. stops when it finds the one you have selected, and tunes in that station



### NOTE 🖄

\* This product may not have the RDS function depending on your region.

#### Setting the Clock

For each step, you have a few seconds to set the required optionals. If you exceed this time, you must start again.

- 1. Switch the system on by pressing the POWER button.
- 2. Press and hold TIMER/CLOCK button and then press the ENTER button.

Result: "CLOCK" is displayed.

3. Press ENTER.

Result: The hour flashes.

- Decrease the hours: ◀
- Increase the hours: ▶
- 4. When the correct hour is displayed, press FNTFR

Result: The minutes flashes.

- Decrease the minutes: ◀
- Increase the minutes: ▶
- 5. When the correct minute is displayed, press

Result: 9 "TIME" appears in the display.

The current time is now set.

### NOTE

- You can display the time, even when you are using another function, by pressing and hold the TIMER/CLOCK button
- You can also use I◄ or ➤I on the top panel instead of buttons in step 3,4.



#### **Timer Function**

The timer enables you to switch the system on or off at specific times automatically.

- Before setting the timer, check that the current time is correct.
- For each step, you have a few seconds to set the required optionals. If you exceed this time, you must start again.
- If you no longer want the system to be switched on or off automatically, you must cancel the timer.

Example: You wish to wake up to music every morning.

- 1. Switch the system on by pressing the POWER button
- 2. Press and hold the TIMER/CLOCK button and then press ✓ or ▶ buttons until OTIME is displayed.
- 3. Press the ENTER ( ) button. Result: ON is displayed for a few seconds, you can set the timer switch-on time.
- Set the timer switch-on time.
  - a Press the ◀ or ▶ button.
  - b Press the ENTER ( ) button. Result: The minutes flash.
  - c Press the ◀ or ▶ button.
  - d Press the ENTER ( ) button.

Result: OFF is displayed for a few seconds, you can now set the timer switch-off time.

- Set the timer switch-off time.
  - a Press the ◀ or ▶ button
  - b Press the ENTER ( ) button.

Result: The minutes flash.

- Press the ◀ or ▶ button.
- d Press the ENTER ( ) button.

Result: VOL XX is displayed, where XX corresponds to the volume already set.

Press ◀ or ▶ button to adjust the volume level and press the ENTER ( ) button. Result: The source to be selected is displayed.

- Press the ◀ or ▶ button to select the desired. source to be played when the system switches on.
  - FM (radio): a Press the ENTER ( → ) button.
    - b Select a preset station by press the ◀ or ▶ button.
  - DVD/CD (compact disc): Load one compact disc.
  - USB: Connect the USB device.

## Basic Functions

Press the ENTER (→) button.

Result: CHK REC (Do you want to record?) is displayed.

Press the ENTER (→) button.

Result: REC N is displayed, you can press the ◀ or ▶ button to select the REC Y or REC N, and then press **ENTER** button

- 1). If you select the REC N, it will cancel tuner timing recording even if you have already set the tuner timing recording.
- 2). If you select the REC Y, you can set the tuner timing recording.
  - a Press the ENTER ( ) button.

Result: ON is displayed for a few seconds, you can set the tuner timing recording switch-on time. b. Press the ENTER ( ) button.

Result: OFF is displayed for a few seconds, you can set the tuner timing recording switch-off time.

### **™** NOTE

- The maximal tuner timing recording time is 5 hours.
- If the timer switch on and off times are identical, the word ERROR is displayed.
- If the switch-on or -off time is the same as the timing recording time, only the switch-on or -off time is effective, and the timing recording time is not applied.
- If there is no disc or usb, when you select the "DVD/CD, USB, it will automatically change to "TUNER".

### Cancelling the Timer

After having set the timer, it will start automatically as shown by the TIMER indication on the display. If you no longer wish to use the timer, you can cancel it.

1. To cancel the timer, press and hold TIMER ON/ OFF once.

Result: (9) is no longer displayed.

To resume the timer, press and hold TIMER ON/ OFF again.

Result: (S) is displayed again.



#### **Sleep Timer Function**

You can set the time that the DVD player will shut itself off.

- 1. Press and hold SLEEP button:
  - Result: The playback starts and the following indications are displayed: 90MIN
- 2. Press and hold the SLEEP button once or more times to indicate how long the system should continue playing before it switches off:

90MIN → 60MIN → 45MIN → 30MIN → 15MIN → SI POFF

#### At any time, you can:

- check the remaining time by pressing and holding the SLEEP button.
- Change the remaining time by repeating steps 1 and 2.
- 3. To cancel the sleep timer, press and hold SLEEP button until SLPOFF appears on the display.



## Advanced Functions

#### **USB Function**

### Playing Media Files using the **USB Host Feature**

You can enjoy media files such as pictures, movies and music saved on an MP3 player, USB memory stick or digital camera in high quality video with 2.0 channel sound by connecting the storage device to the USB port of the product.



- 1. Connect the external USB storage device to the USB iack of the main unit.
- 2. Select the USB mode by pressing the F(@) button on the main unit.
  - · You can select USB by pressing the FUNCTION button on the remote control
- Press the ◀▶ buttons to select Videos. Music or Photo.
  - Select a file to play.

#### Safe USB Removal

To prevent damage to the memory stored in the USB device, perform safe removal before disconnecting the USB cable.

- Press and hold the YELLOW(C) button. - REMOVE will appear on the display.
- · Remove the USB cable.

### **™** NOTE

Remove the USB cable from the USB port slowly. Otherwise, it may cause damage to the USB port.

#### Recording Function



You can record sound of the CD, the Radio Broadcasting or sound from the external source into the USB storage device.

- 1. Switch the system on by pressing the POWER button.
- 2. Connect the external USB storage device you want to record to the USB jack (\*\*) of the main unit
- 3. Play a Disc, adjust the Radio frequency or connect the external source to the main unit

#### CD (See page 19)

- Press the F(m) button on the main unit to select the DVD/CD function.
- Press the OPEN/CLOSE button to open the Disc Compartment.
- Insert a CD and press the OPEN/CLOSE button to close the Disc Compartment.
- Use the CD selection ( I or >> ) button to select the desired song.

#### Tuner (See page 27)

- Press the F( ) button on the main unit to select the FM function.
- Adjust the Radio frequency you want to record.

#### External Source (See page 14)

- Connect an External Component/MP3 player to the main unit.
- Press the FUNCTION button to select the AUX.
- Play a song from the external device.

#### 4. Press the USB REC button to start recording. CD

- "TRACK RECORDING" is displayed and CD recording starts.
- Press and hold the USB REC button to start recording the all tracks of Disc.
  - "FULL CD RECORDING" is displayed.
- If you record the MP3 Disc, the file is copied into the USB device totally.
  - "PROCESSING XX%"" is displayed on TV. When the recording is done, "STOP" will be displayed.
- If there is the same file name. "FILE EXISTED" is displayed on TV, and the function is canceled.

#### Tuner/External Source

"RECORDING" is displayed.

## Advanced Functions

- 5. To stop recording, press the STOP (■) button and then automatically create and save as the MP3 file.
  - After the recording, a directory named "RECORDING" (CD), "CD COPY" (MP3 CD), "TUNER RECORDING" or "AUX RECORDING" will be created in your device.

### NOTE

- Do not disconnect the USB or the AC Cord during the recording as this may cause file damage.
- If you disconnected USB device during the recording, the main unit will be power off and you may not delete the recorded file, In this case, please connect the USB device to the PC and backup the USB data on the PC first and then format the USB device.
- When the USB memory is not enough, it will be displayed "NOT ENOUGH MEMORY".
- The recording works if the USB device or the HDD is formatted in the FAT file system. (The NTFS file system is not supported.)
- When you use CD high speed search function, the CD recording can't work.
- Sometimes, the recording time may be longer with some USB devices. (See page 8)
- When the CD recording, the EQ functions can not work and automatically change to OFF.
- When the CD recording, the REPEAT function can not work and automatically changes to OFF.
- You can not record the radio when searching or no available frequencies in the Tuner mode.
- Note that setting the input level too loud when recording music from an external device through the AUX and USB channel may introduce noise into the recording. In that case, lower the external device's volume level.

### Recording Speed

- Each time you press and hold the CD REC SPEED button on the remote control, the recording speed will change as follows: RECORDSPD x 1→RECORDSPD x 3
  - While the Tuner or External Source is recording, the recording speed does not supported.
  - When you select RECORDSPD x 3, the audio sound will not be output.



Advanced Functions / 05

## Other Information

### Troubleshooting

Refer to the chart below when this unit does not function properly. If the problem you are experiencing is not listed below or if the instruction below does not help, turn off the unit, disconnect the power cord, and contact the nearest authorized dealer or Samsung Electronics Service Center.

Symptom	Check/Remedy
I cannot eject the disc.	Is the power cord plugged securely into the outlet?     Turn off the power and then turn it back on.
Playback does not start.	Check the region number of the DVD. DVD discs purchased from abroad may not be playable. CD-ROMs and DVD-ROMs cannot be played on this product. Make sure that the rating level is correct.
Playback does not start immediately when the Play/Pause button is pressed.	Are you using a deformed disc or a disc with scratches on the surface?     Wipe the disc clean.
Sound is not produced.	No sound is heard during fast playback, slow playback,and step motion playback. Are the speakers connected properly? Is the speaker setup correctly customized? Is the disc severely damaged?
The remote control does not work.	Is the remote control being operated within its operation range of angle and distance?     Are the batteries drained?
<ul> <li>Disc is rotating but no picture is produced.</li> <li>Picture quality is poor and picture is shaking.</li> </ul>	Is the TV power on? Are the video cables connected properly? Is the disc dirty or damaged? A poorly manufactured disc may not be playable.
Audio language and subtitles do not work.	Audio language and subtitles will not work if the disc does not contain them.
The menu screen does not appear even when the menu function is selected.	Are you using a disc that does not contain menus?
Aspect ratio cannot be changed.	You can play 16:9 DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode, or 4:3 PAN SCAN mode, but 4:3 DVDs can be seen in 4:3 ratio only. Refer to the DVD disc jacket and then select the appropriate function.

## Other Information

Symptom	Check/Remedy	
The product is not working. (Example: The power goes out or the top panel key doesn't work or a strange noise is heard.)	While "NO DISC" message appears on the display of the product, press and hold the STOP (■) button on the main unit for longer than 5 seconds with no disc (reset function).	
<ul> <li>The product is not working normally.</li> </ul>	Using the RESET function will erase all stored settings. Do not use this unless necessary.	
The rating level password has been forgotten.	<ul> <li>While "NO DISC" message appears on the display of the product, press and hold the main unit's STOP (</li></ul>	
Can't receive radio broadcast.	Is the antenna connected property?     If the antenna's input signal is weak, install an external FM antenna in an area with good reception.	

### Language code list

Enter the appropriate code number for OTHERS of Disc Menu, Audio and Subtitle. (See page 18).

Code	Language	Code	Language	Code	Language	Code	Language	Code	Language	Code	Language
1027	Afar	1142	Greek	1239	Interlingue	1345	Malagasy	1482	Kirundi	1527	Tajik
1028	Abkhazian	1144	English	1245	Inupiak	1347	Maori	1483	Romanian	1528	Thai
1032	Afrikaans	1145	Esperanto	1248	Indonesian	1349	Macedonian	1489	Russian	1529	Tigrinya
1039	Amharic	1149	Spanish	1253	Icelandic	1350	Malayalam	1491	Kinyarwanda	1531	Turkmen
1044	Arabic	1150	Estonian	1254	Italian	1352	Mongolian	1495	Sanskrit	1532	Tagalog
1045	Assamese	1151	Basque	1257	Hebrew	1353	Moldavian	1498	Sindhi	1534	Setswana
1051	Aymara	1157	Persian	1261	Japanese	1356	Marathi	1501	Sangro	1535	Tonga
1052	Azerbaijani	1165	Finnish	1269	Yiddish	1357	Malay	1502	Serbo-Croatian	1538	Turkish
1053	Bashkir	1166	Fiji	1283	Javanese	1358	Maltese	1503	Singhalese	1539	Tsonga
1057	Byelorussian	1171	Faeroese	1287	Georgian	1363	Burmese	1505	Slovak	1540	Tatar
1059	Bulgarian	1174	French	1297	Kazakh	1365	Nauru	1506	Slovenian	1543	Twi
1060	Bihari	1181	Frisian	1298	Greenlandic	1369	Nepali	1507	Samoan	1557	Ukrainian
1069	Bislama	1183	Irish	1299	Cambodian	1376	Dutch	1508	Shona	1564	Urdu
1066	Bengali; Bangla	1186	Scots Gaelic	1300	Canada	1379	Norwegian	1509	Somali	1572	Uzbek
1067	Tibetan	1194	Galician	1301	Korean	1393	Occitan	1511	Albanian	1581	Vietnamese
1070	Breton	1196	Guarani	1305	Kashmiri	1403	(Afan) Oromo	1512	Serbian	1587	Volapuk
1079	Catalan	1203	Gujarati	1307	Kurdish	1408	Oriya	1513	Siswati	1613	Wolof
1093	Corsican	1209	Hausa	1311	Kirghiz	1417	Punjabi	1514	Sesotho	1632	Xhosa
1097	Czech	1217	Hindi	1313	Latin	1428	Polish	1515	Sundanese	1665	Yoruba
1103	Welsh	1226	Croatian	1326	Lingala	1435	Pashto, Pushto	1516	Swedish	1684	Chinese
1105	Danish	1229	Hungarian	1327	Laothian	1436	Portuguese	1517	Swahili	1697	Zulu
1109	German	1233	Armenian	1332	Lithuanian	1463	Quechua	1521	Tamil		
1130	Bhutani	1235	Interlingua	1334	Latvian, Lettish	1481	Rhaeto- Romance	1525	Tegulu		

		Specifications		
	Weight	1.78 Kg		
General	Dimensions	200 (W) x 142(H) x 207(D) mm		
General	Operating Temperature Range	+5°C~+35°C		
	Operating Humidity Range	10 % to 75 %		
	Signal/noise ratio	55 dB		
FM Tuner	Usable sensitivity	12 dB		
	Total harmonic distortion	0.6 %		
	DVD (Digital Versatile Disc)	Reading Speed: 3.49 ~ 4.06 m/sec.		
	DVD (Digital Versaule Disc)	Approx. Play Time (Single Sided, Single Layer Disc): 135 min.		
Disc(1 Disc)	CD: 12 cm (COMPACT DISC)	Reading Speed: 4.8 ~ 5.6 m/sec.		
Dido(1 Dido)	OD . 12 CIT (OOINI ACT BIOO)	Maximum Play Time : 74 min.		
	CD: 8 cm (COMPACT DISC)	Reading Speed: 4.8 ~ 5.6 m/sec.		
	OB . O GIT (GOINI ACT DIGG)	Maximum Play Time : 20 min.		
		Y : 1.0 Vp-p (75 Ω load)		
Video/Audio	Component Video	Pr : 0.70 Vp-p (75 Ω load)		
		Pb : 0.70 Vp-p (75 Ω load)		
	Front speaker output	35 W/CH (8 <u>∩</u> ) x2		
	Frequency range	20Hz~20KHz		
Amplifier	S/N Ratio	70dB		
	Channel separation	60dB		
	Input sensitivity	(AUX)900mV		

\*: Nominal specification

- Samsung Electronics Co., Ltd reserves the right to change the specifications without notice.
- Weight and dimensions are approximate.
- Design and specifi cations are subject to change without prior notice.
- For the power supply and Power Consumption, refer to the label attached to the product.

### Contact SAMSUNG WORLD WIDE

If you have any questions or comments relating to Samsung products, please contact the SAMSUNG customer care centre.

Area	Contact Center 2	WebSite
■ North Americ	ca	
Canada	1-800-SAMSUNG (726-7864)	www.samsung.com
Mexico	01-800-SAMSUNG (726-7864)	www.samsung.com
U.S.A	1-800-SAMSUNG (726-7864)	www.samsung.com
<ul><li>Latin Americ</li></ul>		
Argentine	0800-333-3733	www.samsung.com
Brazil	0800-124-421 / 4004-0000	www.samsung.com
Chile	800-SAMSUNG (726-7864)	www.samsung.com
Colombia	01-8000112112	www.samsung.com
Costa Rica	0-800-507-7267	www.samsung.com
Dominica	1-800-751-2676	www.samsung.com
Ecuador	1-800-10-7267	www.samsung.com
El Salvador	800-6225 1-800-299-0013	www.samsung.com
Guatemala Honduras	800-7919267	www.samsung.com
Jamaica	1-800-234-7267	www.samsung.com www.samsung.com
Nicaragua	00-1800-5077267	www.samsung.com
Panama	800-7267	www.samsung.com
Peru	0-800-777-08	www.samsung.com
Puerto Rico	1-800-682-3180	www.samsung.com
Trinidad &		V
Tobago	1-800-SAMSUNG (726-7864)	www.samsung.com
Venezuela	0-800-100-5303	www.samsung.com
■ Europe		
Albania	42 27 5755	-
Austria	0810 - SAMSUNG (7267864, € 0.07/min)	www.samsung.com
Belgium	02-201-24-18	www.samsung.com/ be (Dutch) www.samsung.com/ be fr (French)
Bosnia	05 133 1999	-
Bulgaria	07001 33 11	www.samsung.com
Croatia	062 SAMSUNG (062 726 7864)	www.samsung.com
Czech	800-SAMSUNG (800-726786) Samsung Zrt., česká organizační složka, Oasis Florenc, Sokolovská394/17, 180 00, Praha 8	www.samsung.com
Denmark	70 70 19 70	www.samsung.com
Finland	030 - 6227 515	www.samsung.com
France	01 48 63 00 00 01805 - SAMSUNG (726-7864	www.samsung.com
Germany	€ 0,14/Min)	www.samsung.com
Hungary	06-80-SAMSUNG (726-7864)	www.samsung.com
Italia	800-SAMSUNG (726-7864)	www.samsung.com
Kosovo	+381 0113216899	-
Luxemburg	261 03 710	www.samsung.com
Macedonia	023 207 777	-
Montenegro	020 405 888	-
Netherlands	0900-SAMSUNG (0900-7267864) (€ 0,10/Min)	www.samsung.com
Norway	815-56 480	www.samsung.com
Poland	0 801 1SAMSUNG (172678) / 022-607-93-33	www.samsung.com
Portugal	80820-SAMSUNG (726-7864)	www.samsung.com
Rumania	08010 SAMSUNG (72678) - doar din reteaua Romtelecom, tarif local     021.206.01.10 - din orice retea, tarif normal	www.samsung.com

Area	Contact Center 2	WebSite		
Serbia	0700 Samsung (0700 726 7864)	www.samsung.com		
Slovakia	0800-SAMSUNG (726-7864)	www.samsung.com		
Spain	902-1-SAMSUNG (902 172 678)	www.samsung.com		
Sweden	0771 726 7864 (SAMSUNG)	www.samsung.com		
Switzerland	0848-SAMSUNG (7267864, CHF 0.08/min)	www.samsung.com/ch www.samsung.com/ ch_fr/(French)		
U.K	0330 SAMSUNG (7267864)	www.samsung.com		
Eire	0818 717100	www.samsung.com		
Lithuania	8-800-77777	www.samsung.com		
Latvia	8000-7267	www.samsung.com		
Estonia	800-7267	www.samsung.com		
= CIS				
Russia	8-800-555-55-55	www.samsung.com		
Georgia	8-800-555-555			
Armenia	0-800-05-555	-		
Azerbaijan	088-55-55-555	-		
Kazakhstan	8-10-800-500-55-500 (GSM: 7799)	www.samsung.com		
Uzbekistan	8-10-800-500-55-500	www.samsung.com		
Kyrgyzstan	00-800-500-55-500	www.samsung.com		
Tadjikistan	8-10-800-500-55-500	www.samsung.com		
Ukraine	0-800-502-000	www.samsung.ua www.samsung.com/ ua_ru		
Belarus	810-800-500-55-500	-		
Moldova	00-800-500-55-500	-		
<ul> <li>Asia Pacific</li> </ul>				
Australia	1300 362 603	www.samsung.com		
New Zealand	0800 SAMSUNG (0800 726 786)	www.samsung.com		
China	400-810-5858 / 010-6475 1880	www.samsung.com		
Hong Kong	(852) 3698 4698	www.samsung.com/hk www.samsung.com/ hk_en/		
India	3030 8282 / 1800 110011 / 1800 3000 8282 / 1800 266 8282	www.samsung.com		
Indonesia	0800-112-8888 / 021-5699-7777	www.samsung.com		
Japan	0120-327-527	www.samsung.com		
Malaysia	1800-88-9999	www.samsung.com		
Philippines	1-800-10-SAMSUNG(726-7864) / 1-800-3-SAMSUNG(726-7864) / 1-800-8-SAMSUNG(726-7864) / 02-5805777	www.samsung.com		
	1800-SAMSUNG (726-7864)			
Singapore		www.samsung.com		
Singapore Thailand	1800-29-3232 / 02-689-3232	www.samsung.com www.samsung.com		
Thailand	1800-29-3232 / 02-689-3232	www.samsung.com		
Thailand Taiwan	1800-29-3232 / 02-689-3232 0800-329-999	www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam	1800-29-3232 / 02-689-3232 0800-329-999	www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam • Middle East	1800-29-3232 / 02-689-3232 0800-329-999 1 800 588 889	www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam • Middle East Bahrain	1800-29-3232 / 02-689-3232 0800-329-999 1 800 588 889	www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam • Middle East Bahrain Egypt	1800-29-3232 / 02-689-3232 0800-329-999 1 800 588 889 8000-4726 08000-726786	www.samsung.com www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam • Middle East Bahrain Egypt Jordan	1800-29-3232 / 02-689-3232 0800-329-999 1 800-588 889 8000-726786 8000-726786 800-2273 080 100 2255	www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam  • Middle East Bahrain Egypt Jordan Morocco Oman	1800-29-3232 / 02-689-3232 0800-329-999 1 800 588 889 8000-4726 08000-726786 800-22273	www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam  • Middle East Bahrain Egypt Jordan Morocco Oman Saudi Arabia	1800-29-3232 / 02-689-3232 0800-329-999 1 800 588 889 8000-4726 08000-726786 800-22273 080 100 2255 800-SAMSUNG (726-7864)	www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam Middle East Bahrain Egypt Jordan Morocco Oman Saudi Arabia Turkey	1800-29-3232 / 02-689-3232 0800-329-999 1800-88-889 8000-4726 08000-726786 8000-2273 080 100 2255 800-8MSUNG (726-7864) 9200-21230 444 77 11	www.samsung.com		
Thailand Taiwan Vietnam Middle East Bahrain Egypt Jordan Morocco Oman Saudi Arabia Turkey U.A.E	1800-29-3232 / 02-689-3232 0800-329-999 1 800-688-889 8000-4726 08000-726786 800-22273 080 100 2255 080 100 2255 080 100 2255	www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com www.samsung.com		
Thailand Taiwan Vietnam Middle East Bahrain Egypt Jordan Morocco Oman Saudi Arabia Turkey	1800-29-3232 / 02-689-3232 0800-329-999 1800-88-889 8000-4726 08000-726786 8000-2273 080 100 2255 800-8MSUNG (726-7864) 9200-21230 444 77 11	www.samsung.com		





### Correct disposal of batteries in this product(optional)

(Applicable in the European Union and other European countries with separate battery return systems.)

This marking on the battery, manual or packaging indicates that the batteries in this product should not be disposed of with other household waste at the end of their working life. Where marked, the chemical symbols Hg, Cd or Pb indicate that the battery contains mercury, cadmium or lead above the reference levels in EC Directive 2006/66. If batteries are not properly disposed of, these substances can cause harm to human health or the environment.

To protect natural resources and to promote material reuse, please separate batteries from other types of waste and recycle them through your local, free battery return system.



## Correct Disposal of This Product (Waste Electrical & Electronic Equipment(optional)

(Applicable in the European Union and other European countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories (e.g. charger, headset, USB cable) should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources.

Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling.

Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Code No. AH68-02349B(Rev 0.0)